

INSTALLATION INSTRUCTIONS

DODGE DURANGO 1998+UP

PART# 76-20908SB



TOOLS NEEDED

19mm SOCKET
3/4" SOCKET
9/16" SOCKET
RATCHET
TORQUE WRENCH

QTY DESCRIPTION

2	STAINLESS STEP BARS (1 DRIVER SIDE; 1 PASSENGER SIDE)
2	MOUNTING BRACKETS FRONT (1 DRIVER SIDE; 1 PASSENGER SIDE)
2	MOUNTING BRACKETS REAR (1 DRIVER SIDE; 1 PASSENGER SIDE)
4	1/2"-13*2" HEX HEAD BOLT
4	1/2" FLAT WASHERS
4	1/2" LOCK WASHERS

STEPS INSTALLATION

- 1 CHECK CONTENTS OF BOX FOR DAMAGE OR MISSING ITEMS
- 2 BOLT MOUNTING BRACKETS TO STEP BAR (SEE FIGURE 1)
- 3 REMOVE DRIVER SIDE FACTORY BOLTS, POSITION STEP BAR ASSEMBLY TO THE BODY MOUNTS AND INSTALL WITH FACTORY BOLTS.(LEAVE LOOSC)
- 4 REPEAT STEP 3 FOR PASSENGER SIDE.
- 5 CHECK TO MAKE SURE STEP BAR IS PROPERLY ALIGNED WITH VEHICLE BODY. TIGHTEN AND TORQUE 1/2" HARDWARE TO 65 FT/LBS;AND FACTORY BOLTS TO 55 FT/LBS.

